

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST RICHARD J. BYRNE III AGENCY AZ DPS

DATE 01/02/08 TIME 0354

INTOXILYZER SERIAL # 80-000929 LOCATION WICKENBURG P.D.

- (RJB) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
Pour a standard alcohol concentration solution OR N/A AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (RJB) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (RJB) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (RJB) 4. Air blank completed.
- (RJB) 5. Calibration check completed. Test results 0.100 AC.
- (RJB) 6. Air blank completed.
- (RJB) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Richard J. Byrne III #16386


INTOXILYZER 8000
Location: WICKENBURG PD
Serial Number: 80-000929
01/02/2008

03:54:16

Standard Lot#: 603901G
Last Changed By: D. SORTOR #6400

QAS: R. BYRNE, III #6386
AZDPS

Test	g/210L	Time
Air Blank	0.000	03:54:44
Cal Check	0.100	03:55:02
Air Blank	0.000	03:55:32



#6386

Operator's Signature