

DIR 18-032080

COPY

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakely Sr. AGENCY Yavapai County SO

DATE 8-30-18 TIME 04:28:45

INTOXILYZER SERIAL # 80-001019 LOCATION YCSO Prescott

- (x) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution N/A AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (x) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (x) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (x) 4. Air blank completed.
- (x) 5. Calibration check completed. Test results 0.096 AC.
- (x) 6. Air blank completed.
- (x) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakely Sr.

DPS Form Exh G-2 (Rev 05-01)

Tank Serial # 05218100A  
Exp 05-05-2020  
Press 800 psi

DIR 18-032080

INTOXILYZER 8000

Location: YCSO PRESCOTT

Serial Number: 80-001019

Core Version: 8105.48

08/30/2018

04:25:20

-----  
Standard Lot#: 05218100A1

Last Changed By: S. BLAKLEY SR #L6861  
-----

QAS: S. BLAKLEY SR #L6861

YAVAPAI CSO  
-----

Operator: S. BLAKLEY SR #L6861

YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	04:26:09
0.100 Cal Check	0.096	04:26:30
Air Blank	0.000	04:27:00

Preventative Maintenance  
Performed -- Timer Reset

