

CA

**EXHIBIT G-2
 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)
 ARIZONA DEPARTMENT OF PUBLIC SAFETY
 STANDARD QUALITY ASSURANCE PROCEDURES
 INTOXILYZER MODEL 8000
 STANDARD CALIBRATION CHECK PROCEDURE**

QA SPECIALIST DAN RAISS AGENCY YAVAPAI CO. S.O.
 DATE 10-14-08 TIME 1435
 INTOXILYZER SERIAL # 80-001095 LOCATION YCSO-MAYER

- OK) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
 OR
 Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- OK) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- OK) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- OK) 4. Air blank completed.
- OK) 5. Calibration check completed. Test results 0. 097 AC.
- OK) 6. Air blank completed.
- OK) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Amiel Q Rain #5-31/OAS #33026

INTOXILYZER 8000

Location: YCSO-MAYER

Serial Number: 80-001095

10/14/2008

14:57:14

Standard Lot#: 733201G

Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693

YAVAPAI CSO

| Test | g/210L | Time |
|-----------|--------|----------|
| Air Blank | 0.000 | 14:57:41 |
| Cal Check | 0.097 | 14:58:00 |
| Air Blank | 0.000 | 14:58:29 |

Daniel J. Rain #5-31/DAS #33026
Operator's Signature

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST DAN RAISS AGENCY YAVAPAI CO. S.O.
DATE 10-14-08 TIME 1435
INTOXILYZER SERIAL # 80-001095 LOCATION YCSO-MAYER

OK) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- OK) 1. Clock time check.
OK) 2. Date check.

OPERATIONAL TESTS

- OK) 1. Alcohol-free subject test result 0. 000 AC.
OK) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
OK) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
OK) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

ALL OK.

SIGNATURE Daniel J. Raiss

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number : 80-001095
10/14/2008

14:48:37

Standard Lot#: 733201G
Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP ,TEST
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 14:49:31 |
| Diagnostic Test | Pass | 14:49:58 |
| Air Blank | 0.000 | 14:50:26 |
| 0.100 Cal Check | 0.097 | 14:50:44 |
| Air Blank | 0.000 | 14:51:14 |
| Subject Test | 0.109* | 14:54:22 |
| Air Blank | 0.000 | 14:54:54 |
| Air Blank | 0.000 | 14:55:21 |
| Subject Test | XXX** | 14:55:43 |
| Air Blank | 0.000 | 14:56:17 |

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number : 80-001095
10/14/2008

14:47:41

Standard Lot#: 733201G
Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP,TEST,
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------|--------|----------|
| Air Blank | RFI* | 14:48:04 |
| Air Blank | 0.000 | 14:48:32 |

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number : 80-001095
10/14/2008 14:46:31

Standard Lot#: 733201G
Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP,TEST,
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------|--------|----------|
| Air Blank | IPS* | 14:47:07 |
| Air Blank | 0.000 | 14:47:36 |

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YCSO-MAYER

Serial Number : 80-001095

10/14/2008

14:41:14

Standard Lot#: 733201G

Last Changed By: D. RAISS

#3693

QAS: D. RAISS

#3693

YAVAPAI CSO

Operator: D. RAISS

#3693

YAVAPAI CSO

Subject: SQAP,TEST,

DOB: 01/01/1901

Sex: M

Weight: 1

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|------------------|--------|----------|
| Air Blank | 0.000 | 14:42:42 |
| Diagnostic Test | Pass | 14:43:09 |
| Air Blank | 0.000 | 14:43:36 |
| 0.100 Cal Check | 0.098 | 14:43:55 |
| Air Blank | 0.000 | 14:44:25 |
| Subject Test | 0.000 | 14:44:55 |
| Air Blank | 0.000 | 14:45:23 |
| Five Minute Wait | ABT* | |
| Air Blank | 0.000 | 14:46:08 |

*Sequence Aborted

Not a Successfully Completed Test Sequence