

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office
 DATE 3/23/2018 TIME 1354
 INTOXILYZER SERIAL # 80-001095 LOCATION YCSO - Mayer

- (LM)* 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
 OR
 Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. ~~Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (LM)* 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (LM)* 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (LM)* 4. Air blank completed.
- (LM)* 5. Calibration check completed. Test results 0.097 AC.
- (LM)* 6. Air blank completed.
- (LM)* 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE *Logan Moody #7486*

18-000409

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
03/23/2018 13:54:47

Standard Lot#: 06717100A5
Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486
YAVAPAI CSO

Operator: L. MOODY #7486
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	13:55:16
0.100 Cal Check	0.097	13:55:37
Air Blank	0.000	13:56:06

Preventative Maintenance
Performed -- Timer Reset

18-010409

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office

DATE 3/23/2018 TIME 1400

INTOXILYZER SERIAL # 80-001095 LOCATION YCSO - Mayer

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- 1. Clock time check.
- 2. Date check.

OPERATIONAL TESTS

- 1. Alcohol-free subject test result 0. 000 AC.
- 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- 4. Standard Calibration Check standard 0. 100 AC. Result 0. 099 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS 900 psi

SIGNATURE Logan Moody #7486

18-010409

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
03/23/2018

14:00:05

Standard Lot#: 06717100A5
Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486
YAVAPAI CSO

Operator: L. MOODY #7486
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 01/01/1900
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:00:56
Diagnostic Test	Pass	14:01:31
Air Blank	0.000	14:01:58
0.100 Cal Check	0.098	14:02:19
Air Blank	0.000	14:02:49
Subject Test	0.000	14:03:20
Air Blank	ABT*	14:03:28
Air Blank	RFI**	14:03:36

*Sequence Aborted
**RFI Detect

Not a Successfully Completed Test Sequence

18-010409

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
03/23/2018

14:04:04

Standard Lot#: 06717100A5
Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486
YAVAPAI CSO

Operator: L. MOODY #7486
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 01/01/1900
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:04:52
Diagnostic Test	Pass	14:05:27
Air Blank	0.000	14:05:54
0.100 Cal Check	0.098	14:06:15
Air Blank	0.000	14:06:45
Subject Test	0.071*	14:09:52
Air Blank	0.000	14:10:24
Air Blank	0.000	14:10:51
Subject Test	XXX**	14:11:23
Air Blank	IPS***	14:11:30

*Deficient Sample

**Invalid Sample

Begin new deprivation period

***Improper Sample

Not a Successfully Completed Test Sequence

18-010409

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office
DATE 3/23/2018 TIME 1413
INTOXILYZER SERIAL # 80-001095 LOCATION YCSO - Mayer

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution of 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. ~~Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0. 099 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody

18-060409

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
03/23/2018

14:13:02

Standard Lot#: 06717100A5
Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486
YAVAPAI CSO

Operator: L. MOODY #7486
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	14:13:31
0.100 Cal Check	0.099	14:13:52
Air Blank	0.000	14:14:21

Preventative Maintenance
Performed -- Timer Reset