

18-018119

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office

DATE 05/19/2018 TIME 1611

INTOXILYZER SERIAL # 80-0001095 LOCATION YCSO - Mayer

- (u) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
~~Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (u) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (u) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (u) 4. Air blank completed.
- (u) 5. Calibration check completed. Test results 0. 099 AC.
- (u) 6. Air blank completed.
- (u) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody #7486

18-018119

INTOXILYZER 8000  
Location: YCSO-MAYER  
Serial Number: 80-001095  
Core Version: 8105.48  
05/19/2018

16:11:40

-----  
Standard Lot#: 06717100A5  
Last Changed By: L. MOODY #7486  
-----

QAS: L. MOODY #7486  
YAVAPAI CSO  
-----

Operator: L. MOODY #7486  
YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	16:12:43
0.100 Cal Check	0.099	16:13:04
Air Blank	0.000	16:13:33

Preventative Maintenance  
Performed -- Timer Reset