

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Deborah Hughes AGENCY Camp Verde Marshals ofc
DATE 6-27-17 TIME 1244
INTOXILYZER SERIAL # 80-001096 LOCATION CVMO Booking

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 2.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 100 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature]

INTOXILYZER 8000

Location: CAMP VERDE MO

Serial Number: 80-001096

Core Version: 8105.48

06/27/2017

12:44:33

Standard Lot#: 32316100A1

Last Changed By: D. JACOBS #CV08

QAS: D. HUGHES #53

CAMP VERDE MO

Operator: D. HUGHES #53

CAMP VERDE MO

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 12:45:04 |
| 0.100 Cal Check | 0.100 | 12:45:25 |
| Air Blank | 0.000 | 12:45:54 |

Preventative Maintenance
Performed -- Timer Reset