

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST S. A. SOTO #6432 AGENCY AZDPS  
DATE 03/15/2014 TIME 2145  
INTOXILYZER SERIAL = 80-001222 LOCATION YCSO CV JAIL

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0. 100 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE S. A. SOTO #6432

YCSO  
DEPT  
POLICE

INTOXILYZER 8000  
Location: YCSO-VERDE JAIL  
Serial Number: 80-001222  
Core Version: 8105.48  
03/15/2014 21:45:33

-----  
Standard Lot#: 15013100A2  
Last Changed By: R. POOLE #9014  
-----

QAS: S. SOTO #6432  
AZ DPS  
-----

Operator: S. SOTO #6432  
AZ DPS  
-----

Test	g/210L	Time
Air Blank	0.000	21:46:05
0.100 Cal Check	0.100	21:46:26
Air Blank	0.000	21:46:56

Preventative Maintenance  
Performed -- Timer Reset