

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST RT POOLE AGENCY YAVAPAI COUNTY S.O  
DATE 12/31/14 TIME 1746  
INTOXILYZER SERIAL # 80-001222 LOCATION CAMP VERDE JAIL

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START" CONTACT COPS  
(X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
(X) 4. Air blank completed.  
(X) 5. Calibration check completed. Test results 0. 098 AC.  
(X) 6. Air blank completed.  
(X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE \_\_\_\_\_

DPS Form Exh G-2 (Rev 05-01)

350 PSI

CLEARED PRINTER JAM

ADDED PAPER

