

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST JASON DUBIEN AGENCY YAVAPAI COUNTY S.O.  
DATE 02/10/16 TIME 1559 HRS  
INTOXILYZER SERIAL # 80-001222 LOCATION YCSO - CAMP VERDE JAIL

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
~~Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$~~
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0.099 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. DUBIEN 9611/ES4

425 PSI

INTOXILYZER 8000  
Location: YCSO - VERDE JAIL  
Serial Number: 80-001222  
Core Version: 8105.48  
02/10/2016

15:59:49

-----  
Standard Lot#: 26614100A6  
Last Changed By: R. POOLE #9014  
-----

QAS: J. DUBIEN #09611  
YAVAPAI CSO  
-----

Operator: J. DUBIEN #09611  
YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	16:01:06
0.100 Cal Check	0.099	16:01:27
Air Blank	0.000	16:01:56

Preventative Maintenance  
Performed -- Timer Reset