

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST D. Ashby #2271 AGENCY YCSO

DATE 1.15.14 TIME 0938

INTOXILYZER SERIAL # 80.001455 LOCATION Bagdad Substation

(✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration/check completed. Test results 0.099 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE D. Ashby #2271 / QAS# 33400

INTOXILYZER 8000

Location: YAVAPAI SO, BAGDAD

Serial Number: 80-001455

Core Version: 8105.48

01/15/2014

09:38:16

Standard Lot#: 15013100A2

Last Changed By: J. MURRAY #N56

QAS: D. ASHBY #2271

YAVAPAI CSO

Operator: D. ASHBY #2271

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	09:39:05
0.100 Cal Check	0.099	09:39:26
Air Blank	0.000	09:39:56

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST D. Ashby #2271 AGENCY YCSO
DATE 1-15-14 TIME 0942
INTOXILYZER SERIAL # 80-001455 LOCATION Bagdad Substation

(✓) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (✓) 1. Clock time check.
(✓) 2. Date check.

OPERATIONAL TESTS

- (✓) 1. Alcohol-free subject test result 0. 000 AC.
(✓) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
(✓) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
(✓) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 099 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

SIGNATURE

Dann P Ashby #2271 / QAS #33400

INTOXILYZER 8000

Location: YAVAPAI SO, BAGDAD

Serial Number: 80-001455

Core Version: 8105.48

01/15/2014

09:42:46

Standard Lot#: 15013100A2

Last Changed By: J. MURRAY

#N56

QAS: D. ASHBY

#2271

YAVAPAI CSO

Operator: D. ASHBY

#2271

YAVAPAI CSO

Subject: SQAP,TEST

DOB: 01/01/1999

Sex: M

Weight: 150

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	09:43:36
Diagnostic Test	Pass	09:44:11
Air Blank	0.000	09:44:39
0.100 Cal Check	0.099	09:45:00
Air Blank	0.000	09:45:29
Subject Test	0.000	09:45:58
Air Blank	0.000	09:46:25
Wait	ABT*	
Air Blank	0.000	09:47:05

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YAVAPAI SO, BAGDAD
Serial Number: 80-001455
Core Version: 8105.48
01/15/2014

09:48:24

Standard Lot#: 15013100A2
Last Changed By: J. MURRAY #N56

QAS: D. ASHBY #2271
YAVAPAI CSO

Operator: D. ASHBY #2271
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 01/01/1999
Sex: M Weight: 150

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	09:49:10
Air Blank	0.000	09:49:38

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YAVAPAI SO, BAGDAD

Serial Number: 80-001455

Core Version: 8105.48

01/15/2014

09:49:42

Standard Lot#: 15013100A2

Last Changed By: J. MURRAY

#N56

QAS: D. ASHBY

#2271

YAVAPAI CSO

Operator: D. ASHBY

#2271

YAVAPAI CSO

Subject: SQAP, TEST

DOB: 01/01/1999

Sex: M

Weight: 150

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	09:50:08
Air Blank	0.000	09:50:36

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YAVAPAI SO, BAGDAD
Serial Number: 80-001455
Core Version: 8105.48
01/15/2014

09:50:42

Standard Lot#: 15013100A2
Last Changed By: J. MURRAY #N56

QAS: D. ASHBY #2271
YAVAPAI CSO

Operator: D. ASHBY #2271
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 01/01/1999
Sex: M Weight: 150

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	09:51:38
Diagnostic Test	Pass	09:52:14
Air Blank	0.000	09:52:41
0.100 Cal Check	0.099	09:53:02
Air Blank	0.000	09:53:32
Subject Test	0.110*	09:56:39
Air Blank	0.000	09:57:11
Air Blank	0.000	09:57:38
Subject Test	XXX**	09:58:01
Air Blank	0.000	09:58:35

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST D. Ashby #2271 AGENCY YCSO

DATE 1.15.14 TIME 0959

INTOXILYZER SERIAL # 80-001455 LOCATION Bogdad Substation

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 099 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Deann Ashby #2271 / QAS#33400

