

COPY

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. MURRAY AGENCY Yavapai County Sheriff's  
DATE 10/24/11 TIME 11:19:49  
INTOXILYZER SERIAL # 80-01234 LOCATION Seligman

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution. .100 AC.  
OR  
Pour a standard alcohol concentration solution          AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
 4. Air blank completed.  
 5. Calibration check completed. Test results 0.899 AC.  
 6. Air blank completed  
 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. MURRAY NSB

DPS Form Exh G-2 (Rev 05-01)

ON OCCASION OF         

DATE         

AT         

BY

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

10/22/2011

11:19:49

-----  
Standard Lot#: 779386

Last Changed By: J. MURRAY #N56

-----  
QAS: J. MURRAY #N56  
YAVAPAI YCSO

-----  
Operator: J. MURRAY #N56  
YAVAPAI YCSO

-----  
Test                    g/210L                    Time  
-----  
Air Blank                0.000                    11:20:26  
0.100 Cal Check        0.099                    11:20:47  
Air Blank                0.000                    11:21:17

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST J. Murray NSB AGENCY Yavapai County Sheriff's

DATE 10/22/11 TIME 11:24:32

INTOXILYZER SERIAL # 10-017324 LOCATION Seligman

(✓) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (✓) 1. Clock time check.
- (✓) 2. Date check.

OPERATIONAL TESTS

- (✓) 1. Alcohol-free subject test result 0. 0000 AC.
- (✓) 2. Error recognition logic system functioning  
Not a Successfully Completed Test Sequence printed
- (+) 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- (+) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 098 AC.

Instrument is operating properly and accurately. YES X NO    

COMMENTS

QA SERIAL # 800 PSI

DATE SN# 779386 EXP. 6/9/2012

SIGNATURE J. Murray NSB

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
10/22/2011

11:24:02

Standard Lot#: 779386  
Last Changed By: J. MURRAY #N56

OAS: J. MURRAY #N56  
YAVAPAI YCSO

Operator: J. MURRAY #N56  
YAVAPAI YCSO

Subject: TEST, SQAP  
DOB: 10/20/1960  
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	11:27:48
Diagnostic Test	Pass	11:28:22
Air Blank	0.000	11:28:50
0.100 Cal Check	0.099	11:29:11
Air Blank	0.000	11:29:40
Subject Test	0.000	11:30:00
Air Blank	0.000	11:30:27
Wait	ABT*	
Air Blank	IPS**	11:30:40

\* Sequence Aborted  
\*\* Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
10/22/2011

11:30:46

Standard Lot#: 779386  
Last Changed By: J. MURRAY

#N56

OAS: J. MURRAY  
YAVAPAI YCSO

#N56

Operator: J. MURRAY  
YAVAPAI YCSO

#N56

Subject: SQAP, TEST

DOB: 10/20/1960

Sex: F

Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	11:31:36
Air Blank	IPS**	11:31:51

\*RFI Detect

\*\*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
10/22/2011

11:31:55

Standard Lot#: 779386  
Last Changed By: J. MURRAY #N56

OAS: J. MURRAY #N56  
YAVAPAI YCSO

Operator: J. MURRAY #N56  
YAVAPAI YCSO

Subject: SOAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	11:32:47
Diagnostic Test	Pass	11:33:22
Air Blank	0.000	11:33:50
0.100 Cal Check	0.098	11:34:10
Air Blank	0.000	11:34:40
Subject Test	0.459*	11:37:48
Air Blank	0.000	11:38:22
Air Blank	0.000	11:38:50
Subject Test	XXX**	11:39:13
Air Blank	0.000	11:39:48

\*Deficient Sample  
\*\*Invalid Sample  
Begin new deprivation period

Not a Successfully Completed Test Sequence



INFOILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

10/22/2011

11:41:53

-----  
Standard Lot#: 779386

Last Changed By: J. MURRAY #N56

-----  
QAS: J. MURRAY #N56  
YAVAPAI YCSO

-----  
Operator: J. MURRAY #N56  
YAVAPAI YCSO

-----  
Test                    g/210L                    Time  
-----  
Air Blank                0.000                    11:42:27  
0.100 Cal Check        0.098                    11:42:48  
Air Blank                0.000                    11:43:17

Preventative Maintenance  
Performed -- Timer Reset