



INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

10/22/2015

01:44:05

-----  
Standard Lot#: 33913100A3

Last Changed By: J. MURRAY5597 #N56  
-----

QAS: J. MURRAY5597 #N56

YAVAPAI SHERIFFS  
-----

Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFFS  
-----

Test	g/210L	Time
Air Blank	0.000	01:44:44
0.100 Cal Check	0.096	01:45:04
Air Blank	0.000	01:45:34

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST J. MURPHY AGENCY Yavapai County Sheriff's Office

DATE 01/13/16 TIME 01:45:51

INTOXILYZER ID 001734 LOCATION Seligman

(X) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (X) 1. Clock time check.
- (X) 2. Date check.

OPERATIONAL TESTS

- (X) 1. Alcohol-free subject; test result 0. 000 AC.
- (X) 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- (X) 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- (X) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 095 AC.

Instrument is operating properly and accurately. YES X NO     

COMMENTS: Tank SN # 33913100A3 -700 PSE

exp. 1/1/2016

SIGNATURE J. MURPHY NSB/5597

ANALYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Temperature: 8105.48

01:45:51

01:45:51

Standard Lot#: 33913100A3

Last Changed By: J. MURRAY5597 #N56

QA#: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

Subject: SQAP, TEST

DOB: 04/20/1960

Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	01:46:43
Diagnostic Test	Pass	01:47:19
Air Blank	0.000	01:47:46
0.100 Cal Check	0.096	01:48:07
Air Blank	0.000	01:48:36
Subject Test	0.000	01:49:32
Air Blank	0.000	01:49:59
Wait	ABT*	
Air Blank	RFI**	01:50:13

\*Sequence Aborted

\*\*RFI Detect

Not a Successfully Completed Test Sequence

INTERFERER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Position: 8105.48

01:50:17

Lot#: 33913100A3  
Designed By: J. MURRAY5597 #N56

Operator: MURRAY5597 #N56  
YAMAHA SHERIFFS

Operator: J. MURRAY5597 #N56  
YAMAHA SHERIFFS

Substrate: SOAP, TEST

DOB: 02/20/1960

Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	01:50:52
Air Blank	0.000	01:51:21

\*Improper Sample

Not a Successfully Completed Test Sequence

INTOXICATER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
10/22/2005

01:51:26

Standard Lot#: 33913100A3  
Last Changed By: J. MURRAY5597 #N56

QAS: J. MURRAY5597 #N56  
YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56  
YAVAPAI SHERIFFS

Subject: SQAP, TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	01:52:20
Diagnostic Test	Pass	01:52:55
Air Blank	0.000	01:53:22
0.100 Cal Check	0.096	01:53:43
Air Blank	0.000	01:54:13
Subject Test	0.283*	01:57:20
Air Blank	0.000	01:57:52
Air Blank	0.000	01:58:19
Subject Test	XXX**	01:59:00
Air Blank	0.000	01:59:33

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST MURPHY AGENCY Yavapai County Sheriff's Office  
DATE 10/22/15 TIME 1:59:49  
INTOXILYZER SERIAL # 80001734 LOCATION Seligman

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution        AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 095 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murphy NS6/5597

TOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Firmware Version: 8105.48  
07/22/2015

01:59:49

-----  
Standard Lot#: 33913100A3  
Last Changed By: J. MURRAY5597 #N56  
-----

Operator: J. MURRAY5597 #N56  
YAPAI SHERIFFS  
-----

Operator: J. MURRAY5597 #N56  
YAPAI SHERIFFS  
-----

Test	g/210L	Time
Air Blank	0.000	02:00:26
100 Cal Check	0.095	02:00:47
Air Blank	0.000	02:01:16

Preventative Maintenance  
Performed -- Timer Reset