

COPY
ORIGINAL

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST S. Blahley AGENCY Yavapai County Sheriff's Office
DATE 11-16-15 TIME 16:18:49
INTOXILYZER SERIAL # 80-01734 LOCATION YCSO - Seligman

- (/) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution / AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (/) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (/) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (/) 4. Air blank completed.
- (/) 5. Calibration check completed. Test results 0. 097 AC.
- (/) 6. Air blank completed.
- (/) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] LB861/11/12

ORIGINAL COPY

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
11/16/2015

16:18:49

Standard Lot#: 33913100A3
Last Changed By: J. MURRAY5597 #N56

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	16:19:25
0.100 Cal Check	0.097	16:19:45
Air Blank	0.000	16:20:15

Preventative Maintenance
Performed -- Timer Reset

ORIGINAL

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST S. B. Kiley AGENCY Yavapai County Sheriff's Office

DATE 11-16-15 TIME 16:24:16

INTOXILYZER SERIAL # 80-01734 LOCATION YCSO - Seligman

(/) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (/) 1. Clock time check.
- (/) 2. Date check.

OPERATIONAL TESTS

- (/) 1. Alcohol-free subject test result 0. 100 AC.
- (/) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- (/) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- (/) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

Tank Serial # 33913100A3 700 psi Exp 01-01-2016

SIGNATURE [Signature] LSB/11/12

ORIGINAL

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
11/16/2015

16:29:36

Standard Lot#: 33913100A3
Last Changed By: J. MURRAY5597 #N56

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Subject: SQAP, TEST
DOB: 10/26/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	16:30:50
Diagnostic Test	Pass	16:31:25
Air Blank	0.000	16:31:52
0.100 Cal Check	0.097	16:32:13
Air Blank	0.000	16:32:42
Subject Test	0.076*	16:35:50
Air Blank	0.000	16:36:21
Air Blank	0.000	16:36:48
Subject Test	RGE**	16:37:14
Air Blank	RFI***	16:37:30

*Deficient Sample
**Range Exceeded
***RFI Detect

Not a Successfully Completed Test Sequence

COPY ORIGINAL

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

11/16/2015

16:24:16

Standard Lot#: 33913100A3

Last Changed By: J. MURRAY5597 #N56

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Subject: SQAP, TEST

DOB: 10/26/1960

Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	16:26:01
Diagnostic Test	Pass	16:26:36
Air Blank	0.000	16:27:04
0.100 Cal Check	0.097	16:27:24
Air Blank	0.000	16:27:54
Subject Test	0.000	16:28:20
Air Blank	ABT*	16:28:29
Air Blank	IPS**	16:28:38

*Sequence Aborted

**Improper Sample

Not a Successfully Completed Test Sequence

ORIGINAL

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST S. Blakley AGENCY Yavapai County Sheriff's Office
DATE 11-16-15 TIME 16:40:40
INTOXILYZER SERIAL # 80-01734 LOCATION YCSO Seligman

- (x) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution ✓ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (x) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(x) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(x) 4. Air blank completed.
(x) 5. Calibration check completed. Test results 0.092 AC.
(x) 6. Air blank completed.
(x) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] LB/01/1042

ORIGINAL

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
11/16/2015 16:40:40

Standard Lot#: 33913100A3
Last Changed By: J. MURRAY5597 #N56

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	16:41:12
0.100 Cal Check	0.092	16:41:33
Air Blank	0.000	16:42:02

Preventative Maintenance
Performed -- Timer Reset