

COPY

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott E. Blakley Sr. AGENCY Yavapai County SO
DATE 9-6-16 TIME 21:10:06
INTOXILYZER SERIAL # 80-01734 LOCATION Seligman YCSO

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution NA AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.098 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott E. Blakley Sr.

DPS Form Exh G-2 (Rev 05-01)

Tank

Ser. 22315100A1

Pres 700 psi

Exp 9-5-2017

INTOXILYZER 8000

Location: YCSO SRELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

09/06/2016

21:10:06

Standard Lot#: 22315100A1

Last Changed By: J. MURRAY5597 #N56

QAS: S. BLAKLEY SR #L6861

YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861

YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 21:10:41
0.100 Cal Check 0.098 21:11:02
Air Blank 0.000 21:11:31

Preventative Maintenance

Performed -- Timer Reset

Copy

EXHIBIT G-4

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Scott E Blakley Sr. AGENCY Yavapai County SO

DATE 9-6-16 TIME 21:28:11

INTOXILYZER SERIAL # 80-01734 LOCATION YCSO - Seligman

(x) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

(x) 1. Clock time check.

(x) 2. Date check.

OPERATIONAL TESTS

(x) 1. Alcohol-free subject test result 0.000 AC.

(x) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed

(x) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.

(x) 4. Standard Calibration Check standard 0.100 AC. Result 0.098 AC.

Instrument is operating properly and accurately. YES X NO

COMMENTS

Tank Ser 22315100A1

Exp 9-5-2017

Pres 700 ps.

SIGNATURE

Scott E Blakley Sr.

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
09/06/2016

21:28:11

Standard Lot#: 22315100A1
Last Changed By: J. MURRAY5597 #N56

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Subject: SQAP, TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	21:29:52
Diagnostic Test	Pass	21:30:27
Air Blank	0.000	21:30:55
0.100 Cal Check	0.098	21:31:16
Air Blank	0.000	21:31:45
Subject Test	0.000	21:32:22
Air Blank	0.000	21:32:50
Wait	ABT*	
Air Blank	IPS**	21:33:29

*Sequence Aborted

**Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

09/06/2016

21:36:54

Standard Lot#: 22315100A1

Last Changed By: J. MURRAY5597

#N56

QAS: S. BLAKLEY SR

#L6861

YAVAPAI CSO

Operator: S. BLAKLEY SR

#L6861

YAVAPAI CSO

Subject: SOAP,TEST

DOB: 10/20/1960

Sex: F

Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	21:38:04
Diagnostic Test	Pass	21:38:39
Air Blank	0.000	21:39:06
0.100 Cal Check	0.099	21:39:27
Air Blank	RFI*	21:39:52
Air Blank	0.000	21:40:20

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
09/06/2016

21:40:46

Standard Lot#: 22315100A1
Last Changed By: J. MURRAY5597 #N56

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	21:41:49
Diagnostic Test	Pass.	21:42:24
Air Blank	0.000	21:42:51
0.100 Cal Check	0.098	21:43:12
Air Blank	0.000	21:43:41
Subject Test	0.079*	21:46:49
Air Blank	0.000	21:47:20
Air Blank	0.000	21:47:47
Subject Test	XXX**	21:48:20
Air Blank	0.000	21:48:53

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

09/06/2016

21:49:55

Standard Lot#: 22315100A1

Last Changed By: J. MURRAY5597 #N56

QAS: S. BLAKLEY SR #L6861

YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	21:50:26
0.100 Cal Check	0.098	21:50:47
Air Blank	0.000	21:51:16

Preventative Maintenance
Performed -- Timer Reset