

COPY

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. Murray NSB AGENCY Yavapai County Sheriff's Office
DATE 9/4/11 TIME ~~8:41:34~~ 8:41:34
INTOXILYZER SERIAL # 80-000289 LOCATION Piscott Intox Room

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.094 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NSB

INTOXILYZER 8000

Location: YAVAPAI CO. SHERIFF

Serial Number: 80-000289

Core Version: 8105.48

09/04/2011

08:41:34

Standard Lot#: 01011100A1

Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56

YAVAPAI YCSO

Operator: J. MURRAY #N56

YAVAPAI YCSO

Test	g/210L	Time
Air Blank	0.000	08:42:08
0.100 Cal Check	0.094	08:42:29
Air Blank	0.000	08:42:58

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST J. Murray NSB AGENCY Yavapai County Sheriff's Office
DATE 9/4/11 TIME 8:43:36
INTOXILYZER SERIAL # 80-000289 LOCATION Piscott Intox Room

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- 1. Clock time check.
- 2. Date check.

OPERATIONAL TESTS

- 1. Alcohol-free subject test result 0. 000 AC.
- 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- 4. Standard Calibration Check standard 0. 100 AC. Result 0. 094 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS Tank # 0101110A1
exp 2/1/13 1000 PSI

SIGNATURE J. Murray NSB

INTOXILYZER 8000

Location: YAVAPAI CO. SHERIFF

Serial Number: 80-000289

Core Version: 8105.48

09/04/2011

08:43:36

Standard Lot#: 01011100A1

Last Changed By: J. MURRAY

#N56

QAS: J. MURRAY

#N56

YAVAPAI YCSO

Operator: J. MURRAY

#N56

YAVAPAI YCSO

Subject: TEST, SQAP

DOB: 10/20/1960

Sex: F

Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	08:44:34
Diagnostic Test	Pass	08:45:10
Air Blank	0.000	08:45:37
0.100 Cal Check	0.095	08:45:58
Air Blank	0.000	08:46:27
Subject Test	0.000	08:46:49
Air Blank	0.000	08:47:16
Wait	ABT*	
Air Blank	RFI**	08:48:09

*Sequence Aborted

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YAVAPAI CO. SHERIFF

Serial Number: 80-000289

Core Version: 8105.48

09/04/2011

08:48:21

Standard Lot#: 01011100A1

Last Changed By: J. MURRAY

#N56

QAS: J. MURRAY

#N56

YAVAPAI YCSO

Operator: J. MURRAY

#N56

YAVAPAI YCSO

Subject: SQAP,TEST

DOB: 10/20/1960

Sex: F

Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	08:49:00
Air Blank	RFI**	08:49:07

*Improper Sample

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YAVAPAI CO. SHERIFF
Serial Number: 80-000289
Core Version: 8105.48
09/04/2011 08:49:37

Standard Lot#: 01011100A1
Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56
YAVAPAI YCSO

Operator: J. MURRAY #N56
YAVAPAI YCSO

Subject: TEST, SQAP
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	08:50:32
Diagnostic Test	Pass	08:51:07
Air Blank	0.000	08:51:35
0.100 Cal Check	0.094	08:51:56
Air Blank	0.000	08:52:25
Subject Test	0.097*	08:55:32
Air Blank	0.000	08:56:04
Air Blank	0.000	08:56:31
Subject Test	XXX**	08:56:58
Air Blank	0.000	08:57:31

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. RI3-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. Murray NSB AGENCY Yavapai County Sheriff's Office
DATE 9/4/11 TIME 8:58:12
INTOXILYZER SERIAL # 80-000289 LOCATION Pisroff Intox Room

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0. 094 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NSB

INTOXILYZER 8000
Location: YAVAPAI CO. SHERIFF
Serial Number: 80-000289
Core Version: 8105.48
09/04/2011 08:58:12

Standard Lot#: 01011100A1
Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56
YAVAPAI YCSO

Operator: J. MURRAY #N56
YAVAPAI YCSO

Test	g/210L	Time
Air Blank	0.000	08:58:45
0.100 Cal Check	0.094	08:59:06
Air Blank	0.000	08:59:35

Preventative Maintenance
Performed -- Timer Reset