

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPAI CO. S.O.  
DATE 10/10/2012 TIME 1145  
INTOXILYZER SERIAL # 80-000289 LOCATION YCSO DUI TRAILER

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 088 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE LMoody 7486

INTOXILYZER 8000  
Location: YCSO DUI TRAILER  
Serial Number: 80-000289  
Core Version: 8105.48  
10/10/2012

11:45:50

Standard Lot#: 13712100A2  
Last Changed By: L. MOODY #7486

OAS: L. MOODY #7486  
YAUAPAI CSO

Operator: L. MOODY #7486  
YAUAPAI CSO

Test	g/210L	Time
Air Blank	0.000	11:46:37
0.100 Cal Check	0.088*	11:46:57
Air Blank	0.000	11:47:32

\*Calibration Check Out of Tolerance

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST LOGAN MOORE AGENCY YAVAPAI CO. S.O.  
DATE 10/10/12 TIME 1149  
INTOXILYZER SERIAL # 80-000289 LOCATION YCSO DUE TRAILER

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.  
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.  
 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 092 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

---

---

---

---

SIGNATURE LMoore 7486

INTOXILYZER 8000  
Location: YCSO DUI TRAILER  
Serial Number: 80-000289  
Core Version: 8105.48  
10/10/2012 11:49:26

Standard Lot#: 13712100A2  
Last Changed By: L. MOODY #7486

OAS: L. MOODY #7486  
YAUAPAI CSO

Operator: L. MOODY #7486  
YAUAPAI CSO

Subject: SOAP, TEST  
DOB: 01/01/2000  
Sex: M Weight: 190

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	11:50:27
Diagnostic Test	Pass	11:51:05
Air Blank	0.000	11:51:32
0.100 Cal Check	0.094	11:51:53
Air Blank	0.000	11:52:22
Subject Test	0.000	11:53:24
Air Blank	0.000	11:53:51
Wait	ABT*	
Air Blank	RF! **	11:57:16

\*Sequence Aborted  
\*\*RF! Detect

Not a Successfully  
Completed  
Test Sequence

INTOXILYZER 8000  
Location: YCSO DUI TRAILER  
Serial Number: 80-000289  
Core Version: 8105.48  
10/10/2012 11:57:33

Standard Lot#: 13712100A2  
Last Changed By: L. MOODY #7486

OAS: L. MOODY #7486  
YAUAPAI CSO

Operator: L. MOODY #7486  
YAUAPAI CSO

Subject: SOAP, TEST  
DOB: 01/01/2000  
Sex: M Weight: 190

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	11:58:31
Diagnostic Test	Pass	11:59:09
Air Blank	0.000	11:59:36
0.100 Cal Check	0.093	11:59:57
Air Blank	0.000	12:00:26
Subject Test	0.063*	12:03:34
Air Blank	0.000	12:04:05
Air Blank	0.000	12:04:32
Subject Test	XXX**	12:07:09
Air Blank	IPS***	12:07:18

\*Deficient Sample  
\*\*Invalid Sample  
Begin new deprivation period  
\*\*\*Improper Sample

Not a Successfully  
Completed  
Test Sequence

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPAI CO. SO.  
DATE 10/10/12 TIME 1208  
INTOXILYZER SERIAL # 80-000289 LOCATION YCSO DUE TRAILER

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0.092 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Moody 7486

INTOXILYZER 8000  
Location: YCSO DUI TRAILER  
Serial Number: 80-000289  
Core Version: 8105.48  
10/10/2012 12:08:01

-----  
Standard Lot#: 13712100A2  
Last Changed By: L. MOODY #7486  
-----

QAS: L. MOODY #7486  
YAUAPAI CSO  
-----

Operator: L. MOODY #7486  
YAUAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	12:08:31
0.100 Cal Check	0.092	12:08:51
Air Blank	0.000	12:09:20

Preventative Maintenance  
Performed -- Timer Reset