

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moore AGENCY YAVAPAI CO. S.O.
DATE 02/14/2014 TIME 1911
INTOXILYZER SERIAL # 80-000289 LOCATION YUSD - SPARE

- (6) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution - 100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC. into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$~~
- (5) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (5) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (6) 4. Air blank completed.
- (5) 5. Calibration check completed. Test results 0. 093 AC.
- (5) 6. Air blank completed.
- (5) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moore 7486

INTOXILYZER 8000

Location: YCSO DUI TRAILER

Serial Number: 80-000289

Core Version: 8105.48

02/14/2014

19:11:34

Standard Lot#: 13712100A2

Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486

YAVAPAI CSO

Operator: L. MOODY #7486

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	19:14:34
0.100 Cal Check	0.093	19:14:55
Air Blank	0.000	19:15:25

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPAI CO. S.O.
DATE 2/14/2014 TIME 1917
INTOXILYZER SERIAL # 80-000289 LOCATION YCSO - SPARE

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.
 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 094 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

SIGNATURE Logan Moody 7486

INTOXILYZER 8000

Location: YCSO DUI TRAILER

Serial Number: 80-000289

Core Version: 8105.48

02/14/2014

19:17:28

Standard Lot#: 13712100A2

Last Changed By: L. MOODY

#7486

QAS: L. MOODY

#7486

YAVAPAI CSO

Operator: L. MOODY

#7486

YAVAPAI CSO

Subject: SOAP,TEST

DOB: 01/01/2000

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	19:18:20
Diagnostic Test	Pass	19:18:55
Air Blank	0.000	19:19:23
0.100 Cal Check	0.094	19:19:43
Air Blank	0.000	19:20:13
Subject Test	0.000	19:20:30
Air Blank	ABT*	19:20:38
Air Blank	RFI**	19:20:46

*Sequence Aborted

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YCSO DUI TRAILER

Serial Number: 80-000289

Core Version: 8105.48

02/14/2014

19:20:49

Standard Lot#: 13712100A2

Last Changed By: L. MOODY

#7486

OAS: L. MOODY

#7486

YAVAPAI CSO

Operator: L. MOODY

#7486

YAVAPAI CSO

Subject: SOAP,TEST

DOB: 01/01/2000

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	19:21:34
Diagnostic Test	Pass	19:22:09
Air Blank	0.000	19:22:36
0.100 Cal Check	0.094	19:22:57
Air Blank	0.000	19:23:26
Subject Test	0.137*	19:26:34
Air Blank	0.000	19:27:05
Air Blank	0.000	19:27:33
Subject Test	XXX**	19:28:01
Air Blank	IPS***	19:28:09

*Deficient Sample

**Invalid Sample

Begin new deprivation period

***Improper Sample

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPAI CO. S.O.
DATE 2/14/2014 TIME 1929
INTOXILYZER SERIAL # 80 000289 LOCATION YCSO - SPARE

- BT* 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution ~100 AC.
OR
~~*Pour a standard alcohol concentration solution _____ AC. into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (CN)* 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(CN) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(CN) 4. Air blank completed.
(CN) 5. Calibration check completed. Test results 0. 094 AC.
(CN) 6. Air blank completed.
(CN) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody 7486

INTOXILYZER 8000

Location: YCSO DUI TRAILER

Serial Number: 80-000289

Core Version: 8105.48

02/14/2014

19:28:24

Standard Lot#: 13712100A2

Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486

YAVAPAI CSO

Operator: L. MOODY #7486

YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 19:28:52
Reference UNS* 19:29:00
Air Blank 0.000 19:29:28

*Unstable Signal

INTOXILYZER 8000

Location: YCSO DUI TRAILER

Serial Number: 80-000289

Core Version: 8105.48

02/14/2014

19:29:30

Standard Lot#: 13712100A2

Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486

YAVAPAI CSO

Operator: L. MOODY #7486

YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 19:29:59
0.100 Cal Check 0.094 19:30:20
Air Blank 0.000 19:30:49

Preventative Maintenance
Performed -- Timer Reset