

17-006994

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)
ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office
DATE 2/26/2017 TIME 0116
INTOXILYZER SERIAL # 80-000289 LOCATION YCSO - Black Canyon

- (C) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$~~
- (C) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (C) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (C) 4. Air blank completed.
- (C) 5. Calibration check completed. Test results 0. 099 AC.
- (C) 6. Air blank completed.
- (C) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody #7486

17-006994

INTOXILYZER 8000

Location: YCSO - BLACK CANYON

Serial Number: 80-000289

Core Version: 8105.48

02/26/2017

01:16:01

Standard Lot#: 23016100A1

Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486

YAVAPAI CSO

Operator: L. MOODY #7486

YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 01:17:01
0.100 Cal Check 0.099 01:17:22
Air Blank 0.000 01:17:52

Preventative Maintenance
Performed -- Timer Reset