

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office

DATE 02/01/2018 TIME 0949

INTOXILYZER SERIAL # 80-000289 LOCATION YCSO - Black Canyon

- (M) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (M) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (M) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (M) 4. Air blank completed.
- (M) 5. Calibration check completed. Test results 0. 097 AC.
- (M) 6. Air blank completed.
- (M) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody

18-003903

INTOXILYZER 8000
Location: YCSO - BLACK CANYON
Serial Number: 80-000289
Core Version: 8105.48
02/01/2018 09:49:38

Standard Lot#: 23016100A1
Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486
YAVAPAI CSO

Operator: L. MOODY #7486
YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 09:50:07
0.100 Cal Check 0.097 09:50:28
Air Blank 0.000 09:50:57

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office

DATE 02/01/2018 TIME 0936

INTOXILYZER SERIAL # 80-000289 LOCATION YCSO - Black Canyon

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 1.00 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0. 098 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody #7486

18-003903

INTOXILYZER 8000
Location: YCSO - BLACK CANYON
Serial Number: 80-000289
Core Version: 8105.48
02/01/2018 09:36:44

Standard Lot#: 23016100A1
Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486
YAVAPAI CSO

Operator: L. MOODY #7486
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	09:37:16
0.100 Cal Check	0.098	09:37:37
Air Blank	0.000	09:38:06

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office

DATE 02/01/2018 TIME 0938

INTOXILYZER SERIAL # 80-000289 LOCATION YCSO - Black Canyon

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- 1. Clock time check.
- 2. Date check.

OPERATIONAL TESTS

- 1. Alcohol-free subject test result 0. 000 AC.
- 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS 925 psi

SIGNATURE Logan Moody 2476

INTOXILYZER 8000
 Location: YCSO - BLACK CANYON
 Serial Number: 80-000289
 Core Version: 8105.48
 02/01/2018 09:38:31

Standard Lot#: 23016100A1
 Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486
 YAVAPAI CSO

Operator: L. MOODY #7486
 YAVAPAI CSO

Subject: SQAP,TEST
 DOB: 01/01/1990
 Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	09:39:21
Diagnostic Test	Pass	09:39:56
Air Blank	0.000	09:40:24
0.100 Cal Check	0.097	09:40:44
Air Blank	0.000	09:41:14
Subject Test	0.000	09:41:42
Air Blank	ABT*	09:41:53
Air Blank	RFI**	09:42:00

*Sequence Aborted

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YCSO - BLACK CANYON

Serial Number: 80-000289

Core Version: 8105.48

02/01/2018

09:42:07

Standard Lot#: 23016100A1

Last Changed By: L. MOODY

#7486

QAS: L. MOODY

#7486

YAVAPAI CSO

Operator: L. MOODY

#7486

YAVAPAI CSO

Subject: SQAP, TEST

DOB: 01/01/1990

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	09:42:52
Diagnostic Test	Pass	09:43:27
Air Blank	0.000	09:43:55
0.100 Cal Check	0.097	09:44:15
Air Blank	0.000	09:44:45
Subject Test	0.082*	09:47:52
Air Blank	0.000	09:48:23
Air Blank	0.000	09:48:51
Subject Test	XXX**	09:49:17
Air Blank	IPS***	09:49:25

*Deficient Sample

**Invalid Sample

Begin new deprivation period

***Improper Sample

Not a Successfully Completed Test Sequence