

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST T. B. Bin AGENCY P. V. P. D.  
DATE 02-06-2008 TIME 1454  
INTOXILYZER SERIAL # 80-000293 LOCATION P. V. P. D.

*JPT*) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- JPT* 1. Clock time check.  
*JPT* 2. Date check.

OPERATIONAL TESTS

- JPT* 1. Alcohol-free subject test result 0. 000 AC.  
*JPT* 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
*JPT* 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
*JPT* 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES *JPT* NO

COMMENTS

ADJUSTED CLOCK FROM "14:37" TO "14:45"  
(DISPATCH TIME) AT START OF SQAP. INSTRUMENT  
OPERATING PROPERLY & ACCURATELY.

SIGNATURE *J. Chi #73*

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number : 80-000293

02/06/2008

14:47:00

Standard Lot#: 706502I

Last Changed By: J. TOBIN

#73

QAS: J. TOBIN

#73

PRESCOTT VALLEY PD

Operator: J. TOBIN

#73

PRESCOTT VALLEY PD

Subject: SQAP,TEST

DOB: 06/25/1967

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:48:23
Diagnostic Test	Pass	14:48:50
Air Blank	0.000	14:49:18
0.100 Cal Check	0.099	14:49:36
Air Blank	0.000	14:50:06
Subject Test	0.000	14:50:31
Air Blank	0.000	14:50:59
Five Minute Wait	ABT*	
Air Blank	0.000	14:51:37

\*Sequence Aborted

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number : 80-000293

02/06/2008

14:51:50

Standard Lot#: 706502I

Last Changed By: J. TOBIN

#73

QAS: J. TOBIN

#73

PRESCOTT VALLEY PD

Operator: J. TOBIN

#73

PRESCOTT VALLEY PD

Subject: SQAP,TEST

DOB: 06/25/1967

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	14:52:33
Air Blank	0.000	14:53:02

\*Improper Sample

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number : 80-000293

02/06/2008

14:53:18

Standard Lot#: 706502I

Last Changed By: J. TOBIN #73

QAS: J. TOBIN #73

PRESCOTT VALLEY PD

Operator: J. TOBIN #73

PRESCOTT VALLEY PD

Subject: SQAP,TEST

DOB: 06/25/1967

Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	14:54:05
Air Blank	0.000	14:54:33

\*RFI Detect

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number : 80-000293

02/06/2008

14:54:38

Standard Lot#: 706502I

Last Changed By: J. TOBIN

#73

QAS: J. TOBIN

#73

PRESCOTT VALLEY PD

Operator: J. TOBIN

#73

PRESCOTT VALLEY PD

Subject: SQAP,TEST

DOB: 06/25/1967

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:55:45
Diagnostic Test	Pass	14:56:12
Air Blank	0.000	14:56:39
0.100 Cal Check	0.098	14:56:58
Air Blank	0.000	14:57:27
Subject Test	0.178*	15:00:36
Air Blank	0.000	15:01:07
Air Blank	0.000	15:01:35
Subject Test	XXX**	15:01:56
Air Blank	0.000	15:02:30

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

**Not a Successfully Completed Test Sequence**

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST TOBIN AGENCY P.V.P.D.  
DATE 02-06-2008 TIME 1435  
INTOXILYZER SERIAL # 80-000293 LOCATION P.V.P.D.

- JPT* 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution N/A AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- JPT*  
*OPT* 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
*OPT* 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
*OPT* 4. Air blank completed.  
*OPT* 5. Calibration check completed. Test results 0. 099 AC.  
*OPT* 6. Air blank completed.  
*OPT* 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE *J. Smith #73*

DPS Form Exh G-2 (Rev 05-01)

CALIBRATION PRIOR TO SQAP

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number: 80-000293

02/06/2008

14:35:35

-----  
Standard Lot#: 706502I

Last Changed By: J. TOBIN #73  
-----

QAS: J. TOBIN #73

PRESCOTT VALLEY PD  
-----

Test	g/210L	Time
Air Blank	0.000	14:36:03
Cal Check	0.099	14:36:21
Air Blank	0.000	14:36:51



-----  
Operator's Signature

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST TOBIN #73 AGENCY P.V.P.D.  
DATE 02-06-2008 TIME 15:04  
INTOXILYZER SERIAL # 80-000293 LOCATION P.V.P.D.

- PPT* 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
Pour a standard alcohol concentration solution <sup>OR</sup> N/A AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- PPT*  
*OPT* 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- SPT*  
*SPT*  
*GPT*  
*SPT* 4. Air blank completed.  
5. Calibration check completed. Test results 0. 097 AC.  
6. Air blank completed.  
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE *Jim Witt #73*

DPS Form Exh G-2 (Rev 05-01)

CALIBRATION AFTER SQAP

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number: 80-000293

02/06/2008

15:04:36


-----  
Standard Lot#: 706502I

Last Changed By: J. TOBIN #73  
-----

QAS: J. TOBIN #73

PRESCOTT VALLEY PD  
-----

Test	g/210L	Time
Air Blank	0.000	15:05:04
Cal Check	0.097	15:05:22
Air Blank	0.000	15:05:52



-----  
Operator's Signature