

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST T. LAWRENCE AGENCY Prescott Valley PD.
DATE 3-26-15 TIME 2106
INTOXILYZER SERIAL # 80-000293 LOCATION PVPD / Booking

- (4) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (4) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (4) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (4) 4. Air blank completed.
- (4) 5. Calibration check completed. Test results 0. 099 AC.
- (4) 6. Air blank completed.
- (4) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] # 61

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number: 80-000293

Core Version: 8105.48

03/26/2015

21:06:50

Standard Lot#: 26614100A6

Last Changed By: A. LAWRENCE #61

QAS: A. LAWRENCE #61

PRESCOTT VALLEY PD

Operator: A. LAWRENCE #61

PRESCOTT VALLEY PD

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 21:07:25 |
| 0.100 Cal Check | 0.099 | 21:07:46 |
| Air Blank | 0.000 | 21:08:15 |

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST T. LAWRENCE AGENCY Prescott Valley PD
DATE 3-26-15 TIME 2108
INTOXILYZER SERIAL # 80-000293 LOCATION PVPD / Booking Room

() 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- () 1. Clock time check.
() 2. Date check.

OPERATIONAL TESTS

- () 1. Alcohol-free subject test result 0. 000 AC.
() 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
() 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
() 4. Standard Calibration Check standard 0. 100 AC. Result 0. 099 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

NO ISSUES WITH THE INTOXILYZER 8000
Working Properly

SIGNATURE [Signature] #61

INTOXILYZER 8000
Location: PRESCOTT VALLEY PD
Serial Number: 80-000293
Core Version: 8105.48
03/26/2015

21:08:27

Standard Lot#: 26614100A6
Last Changed By: A. LAWRENCE #61

QAS: A. LAWRENCE #61
PRESCOTT VALLEY PD

Operator: A. LAWRENCE #61
PRESCOTT VALLEY PD

Subject: SQAP, TEST
DOB: 01/05/1980
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 21:09:19 |
| Diagnostic Test | Pass | 21:09:53 |
| Air Blank | 0.000 | 21:10:21 |
| 0.100 Cal Check | 0.099 | 21:10:42 |
| Air Blank | 0.000 | 21:11:11 |
| Subject Test | 0.000 | 21:11:25 |
| Air Blank | 0.000 | 21:11:53 |
| Wait | ABT* | |
| Air Blank | 0.000 | 21:12:27 |

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: PRESCOTT VALLEY PD
Serial Number: 80-000293
Core Version: 8105.48
03/26/2015

21:12:33

Standard Lot#: 26614100A6
Last Changed By: A. LAWRENCE #61

QAS: A. LAWRENCE #61
PRESCOTT VALLEY PD

Operator: A. LAWRENCE #61
PRESCOTT VALLEY PD

Subject: SQAP, TEST
DOB: 01/05/1980
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------|--------|----------|
| Air Blank | IPS* | 21:13:09 |
| Air Blank | 0.000 | 21:13:37 |

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: PRESCOTT VALLEY PD
Serial Number: 80-000293
Core Version: 8105.48
03/26/2015 21:13:46

Standard Lot#: 26614100A6
Last Changed By: A. LAWRENCE #61

QAS: A. LAWRENCE #61
PRESCOTT VALLEY PD

Operator: A. LAWRENCE #61
PRESCOTT VALLEY PD

Subject: SQAP, TEST
DOB: 01/05/1980
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------|--------|----------|
| Air Blank | RFI* | 21:14:19 |
| Air Blank | 0.000 | 21:14:47 |

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: PRESCOTT VALLEY PD
Serial Number: 80-000293
Core Version: 8105.48
03/26/2015

21:14:50

Standard Lot#: 26614100A6
Last Changed By: A. LAWRENCE #61

QAS: A. LAWRENCE #61
PRESCOTT VALLEY PD

Operator: A. LAWRENCE #61
PRESCOTT VALLEY PD

Subject: SQAP, TEST
DOB: 01/05/1980
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 21:15:35 |
| Diagnostic Test | Pass | 21:16:09 |
| Air Blank | 0.000 | 21:16:36 |
| 0.100 Cal Check | 0.099 | 21:16:57 |
| Air Blank | 0.000 | 21:17:26 |
| Subject Test | 0.188* | 21:20:34 |
| Air Blank | 0.000 | 21:21:06 |
| Air Blank | 0.000 | 21:21:33 |
| Subject Test | XXX** | 21:21:59 |
| Air Blank | 0.000 | 21:22:33 |

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST T. LAWRENCE AGENCY Prescott Valley PD
DATE 3-26-15 TIME 2122
INTOXILYZER SERIAL # 80-000293 LOCATION PVPD/ Booking Room

- (4) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (4) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (4) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (4) 4. Air blank completed.
- (4) 5. Calibration check completed. Test results 0. 098 AC.
- (2) 6. Air blank completed.
- (4) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE T. Lawrence #61

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number: 80-000293

Core Version: 8105.48

03/26/2015

21:22:47

Standard Lot#: 26614100A6

Last Changed By: A. LAWRENCE #61

QAS: A. LAWRENCE #61

PRESCOTT VALLEY PD

Operator: A. LAWRENCE #61

PRESCOTT VALLEY PD

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 21:23:17 |
| 0.100 Cal Check | 0.098 | 21:23:37 |
| Air Blank | 0.000 | 21:24:07 |

Preventative Maintenance
Performed -- Timer Reset