

PROPERTY INVOICE AND RECEIPT

NOTE: FILL IN EVERY SPACE UNLESS THE INFORMATION IS NOT AVAILABLE PRINT LEGIBLY IN INK.		TYPE OF PROPERTY (Circle One Only)	DATE AND TIME PROPERTY SEIZED	
		<u>EVIDENCE</u>	SAFEKEEPING	FOUND
NAME OF VICTIM OR OWNER (LAST, FIRST, MIDDLE)		ADDRESS		TELEPHONE
CITY OF COTTONWOOD				13-006295
NAME OF PERSON ARRESTED, OR SUSPECT (LAST, FIRST, MIDDLE)		ADDRESS		TELEPHONE
				D.O.B.
NAME OF PERSON ARRESTED, OR SUSPECT (LAST, FIRST, MIDDLE)		ADDRESS		TELEPHONE
				D.O.B.
NAME OF FINDER OR PERSON REPORTING FOUND PROPERTY		ADDRESS		TELEPHONE
				CITATION #
CHARGES			FINDER WILL CLAIM PROPERTY	LAB TEST
			YES NO	YES NO

NOTIFICATION FOR RETURN OF PERSONAL PROPERTY

You are responsible for claiming your personal property within 90 days from the above date. The property will be disposed of by the Cottonwood Police Department, if no claim is made prior to that date.

ADVANCE AUTHORIZATION IS REQUIRED IF YOU WISH TO DESIGNATE ANOTHER PERSON TO RECEIVE YOUR PROPERTY.

SIGNATURE _____

BRIEF SYNOPSIS OF OCCURRENCE: (Also use this space for additional suspects or victims)			
90 DAY SQAP			
ITEMIZE AND DESCRIBE PROPERTY			
LIST ONLY ONE ITEM PER LINE. NUMBER EACH ITEM ON THE FORM. - Where possible, place each item in plastic bag, and attach property tag to outside of bag.			
ITEM	DESCRIPTION	SERIAL #	PROPERTY #
1A	SQAP PAPER WORK	80-004765	89279
Placed in Property Locker # 7		Date 5/23/13	Time 1559
OFFICER: OFC [Signature]		SERIAL: 592	PAGE 1 OF 1
DISPOSITION OF PROPERTY:			
Property Items Were:			
1. Returned to Owner		3. Sold at Auction	
2. Destroyed		5. Left at Court	
6. Unable to Locate			
Received By [Signature]	Date 5/24/13	Time 0945	Remarks
Property Location [Signature]			

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST SCARM, ROGER G AGENCY COTTONWOOD PD
DATE 5/23/13 TIME ~~1514~~ 1514
INTOXILYZER SERIAL # 85-004765 LOCATION COTTONWOOD PD

(1) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (1) 1. Clock time check.
(1) 2. Date check.

OPERATIONAL TESTS

- (1) 1. Alcohol-free subject test result 0. 000 AC.
(1) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
(1) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed. 0.800
(1) 4. Standard Calibration Check standard 0. 0.999 AC. Result 0. 0.99 AC.

Instrument is operating properly and accurately. YES 1 NO _____

COMMENTS

SIGNATURE OKC [Signature] 592

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST SCARIM, ROGER G. AGENCY COTTONWOOD PD
DATE 5/23/13 TIME 1506
INTOXILYZER SERIAL # 80-004765 LOCATION COTTONWOOD PD

- (M) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (M) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (M) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (M) 4. Air blank completed.
- (M) 5. Calibration check completed. Test results 0. 095 AC.
- (M) 6. Air blank completed.
- (M) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE ^{ofc} [Signature] 592

INTOXILYZER 8000

Location: COTTONWOOD PD

Serial Number: 80-004765

Core Version: 8105.48

05/23/2013

15:10:57

Standard Lot#: 26212100A1

Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592

COTTONWOOD PD

Operator: R. SCARIM #592

COTTONWOOD PD

Test	g/210L	Time
Air Blank	0.000	15:11:29
0.100 Cal Check	0.095	15:11:50
Air Blank	0.000	15:12:19

Preventative Maintenance
Performed -- Timer Reset

13-006295

INTOXILYZER 8000

Location: COTTONWOOD PD

Serial Number: 80-004765

Core Version: 8105.48

05/23/2013

15:15:26

Standard Lot#: 26212100A1

Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592

COTTONWOOD PD

Operator: R. SCARIM #592

COTTONWOOD PD

Subject: SQAP,TEST

DOB: 11/11/1911

Sex: M

Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	15:16:53
Diagnostic Test	Pass	15:17:28
Air Blank	0.000	15:17:56
0.100 Cal Check	0.097	15:18:17
Air Blank	0.000	15:18:46
Subject Test	0.000	15:19:01
Air Blank	0.000	15:19:29
Wait	ABT*	
Air Blank	0.000	15:20:03

*Sequence Aborted

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000

Location: COTTONWOOD PD

Serial Number: 80-004765

Core Version: 8105.48

05/23/2013

15:15:26

Standard Lot#: 26212100A1

Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592

COTTONWOOD PD

Operator: R. SCARIM #592

COTTONWOOD PD

Subject: SQAP, TEST

DOB: 11/11/1911

Sex: M

Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	15:16:53
Diagnostic Test	Pass	15:17:28
Air Blank	0.000	15:17:56
0.100 Cal Check	0.097	15:18:17
Air Blank	0.000	15:18:46
Subject Test	0.000	15:19:01
Air Blank	0.000	15:19:29
Wait	ABT*	
Air Blank	0.000	15:20:03

*Sequence Aborted

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000
Location: COTTONWOOD PD
Serial Number: 80-004765
Core Version: 8105.48
05/23/2013

15:15:26

Standard Lot#: 26212100A1
Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592
COTTONWOOD PD

Operator: R. SCARIM #592
COTTONWOOD PD

Subject: SQAP,TEST
DOB: 11/11/1911
Sex: M

Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	15:16:53
Diagnostic Test	Pass	15:17:28
Air Blank	0.000	15:17:56
0.100 Cal Check	0.097	15:18:17
Air Blank	0.000	15:18:46
Subject Test	0.000	15:19:01
Air Blank	0.000	15:19:29
Wait	ABT*	
Air Blank	0.000	15:20:03

*Sequence Aborted

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000

Location: COTTONWOOD PD

Serial Number: 80-004765

Core Version: 8105.48

05/23/2013

15:20:42

Standard Lot#: 26212100A1

Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592

COTTONWOOD PD

Operator: R. SCARIM #592

COTTONWOOD PD

Subject: SQAP,TEST

DOB: 11/11/1911

Sex: M

Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	15:21:25
Air Blank	0.000	15:21:54

*Improper Sample

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000
Location: COTTONWOOD PD
Serial Number: 80-004765
Core Version: 8105.48
05/23/2013

15:20:42

Standard Lot#: 26212100A1
Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592
COTTONWOOD PD

Operator: R. SCARIM #592
COTTONWOOD PD

Subject: SQAP,TEST

DOB: 11/11/1911

Sex: M

Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	15:21:25
Air Blank	0.000	15:21:54

*Improper Sample

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000
Location: COTTONWOOD PD
Serial Number: 80-004765
Core Version: 8105.48
05/23/2013

15:20:42

Standard Lot#: 26212100A1
Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592
COTTONWOOD PD

Operator: R. SCARIM #592
COTTONWOOD PD

Subject: SQAP,TEST
DOB: 11/11/1911
Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	15:21:25
Air Blank	0.000	15:21:54

*Improper Sample

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000
Location: COTTONWOOD PD
Serial Number: 80-004765
Core Version: 8105.48
05/23/2013

15:22:35

Standard Lot#: 26212100A1
Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592
COTTONWOOD PD

Operator: R. SCARIM #592
COTTONWOOD PD

Subject: SQAP, TEST
DOB: 11/11/1911
Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	15:23:15
Air Blank	0.000	15:23:44

*RFI Detect

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000
Location: COTTONWOOD PD
Serial Number: 80-004765
Core Version: 8105.48
05/23/2013

15:22:35

Standard Lot#: 26212100A1
Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592
COTTONWOOD PD

Operator: R. SCARIM #592
COTTONWOOD PD

Subject: SQAP,TEST
DOB: 11/11/1911
Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	15:23:15
Air Blank	0.000	15:23:44

*RFI Detect

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000
Location: COTTONWOOD PD
Serial Number: 80-004765
Core Version: 8105.48
05/23/2013

15:22:35

Standard Lot#: 26212100A1
Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592
COTTONWOOD PD

Operator: R. SCARIM #592
COTTONWOOD PD

Subject: SQAP, TEST
DOB: 11/11/1911

Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	15:23:15
Air Blank	0.000	15:23:44

*RFI Detect

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000
Location: COTTONWOOD PD
Serial Number: 80-004765
Core Version: 8105.48
05/23/2013

15:25:42

Standard Lot#: 26212100A1
Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592
COTTONWOOD PD

Operator: R. SCARIM #592
COTTONWOOD PD

Subject: SQAP,TEST
DOB: 11/11/1911
Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	15:26:43
Diagnostic Test	Pass	15:27:18
Air Blank	0.000	15:27:46
0.100 Cal Check	0.099	15:28:07
Air Blank	0.000	15:28:36
Subject Test	0.036*	15:31:44
Air Blank	0.000	15:32:16
Air Blank	0.000	15:32:44
Subject Test	XXX**	15:32:57
Air Blank	0.000	15:33:30

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000
Location: COTTONWOOD PD
Serial Number: 80-004765
Core Version: 8105.48
05/23/2013

15:25:42

Standard Lot#: 26212100A1
Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592
COTTONWOOD PD

Operator: R. SCARIM #592
COTTONWOOD PD

Subject: SQAP,TEST
DOB: 11/11/1911
Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	15:26:43
Diagnostic Test	Pass	15:27:18
Air Blank	0.000	15:27:46
0.100 Cal Check	0.099	15:28:07
Air Blank	0.000	15:28:36
Subject Test	0.036*	15:31:44
Air Blank	0.000	15:32:16
Air Blank	0.000	15:32:44
Subject Test	XXX**	15:32:57
Air Blank	0.000	15:33:30

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

13-006295

INTOXILYZER 8000

Location: COTTONWOOD PD

Serial Number: 80-004765

Core Version: 8105.48

05/23/2013

15:25:42

Standard Lot#: 26212100A1

Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592

COTTONWOOD PD

Operator: R. SCARIM #592

COTTONWOOD PD

Subject: SQAP,TEST

DOB: 11/11/1911

Sex: M

Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	15:26:43
Diagnostic Test	Pass	15:27:18
Air Blank	0.000	15:27:46
0.100 Cal Check	0.099	15:28:07
Air Blank	0.000	15:28:36
Subject Test	0.036*	15:31:44
Air Blank	0.000	15:32:16
Air Blank	0.000	15:32:44
Subject Test	XXX**	15:32:57
Air Blank	0.000	15:33:30

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

13-006295

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scarnin, ROGER G. AGENCY COTTONWOOD PD
DATE 5/23/13 TIME 1534
INTOXILYZER SERIAL # 80-004765 LOCATION COTTONWOOD PD

- (A) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (M) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (M) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (M) 4. Air blank completed.
- (M) 5. Calibration check completed. Test results 0. 099 AC.
- (M) 6. Air blank completed.
- (M) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE osc [Signature] 592

DPS Form Exh G-2 (Rev 05-01)

13-006295

INTOXILYZER 8000

Location: COTTONWOOD PD

Serial Number: 80-004765

Core Version: 8105.48

05/23/2013

15:34:47

Standard Lot#: 26212100A1

Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592

COTTONWOOD PD

Operator: R. SCARIM #592

COTTONWOOD PD

Test	g/210L	Time
Air Blank	0.000	15:35:19
0.100 Cal Check	0.099	15:35:40
Air Blank	0.000	15:36:09

Preventative Maintenance
Performed -- Timer Reset

13-006295