

PROPERTY INVOICE AND RECEIPT

NOTE: FILL IN EVERY SPACE UNLESS THE INFORMATION IS NOT AVAILABLE PRINT LEGIBLY IN INK.		TYPE OF PROPERTY (Circle One Only)		DATE AND TIME PROPERTY SEIZED	
		<u>EVIDENCE</u>	SAFEKEEPING	FOUND	9/5/15 1932
NAME OF VICTIM OR OWNER (LAST, FIRST, MIDDLE)		ADDRESS		TELEPHONE	D.R. NUMBER
CITY OF COTTONWOOD					15-009784
NAME OF PERSON ARRESTED, OR SUSPECT (LAST, FIRST, MIDDLE)		ADDRESS		TELEPHONE	D.O.B.
NAME OF PERSON ARRESTED, OR SUSPECT (LAST, FIRST, MIDDLE)		ADDRESS		TELEPHONE	D.O.B.
NAME OF FINDER OR PERSON REPORTING FOUND PROPERTY		ADDRESS		TELEPHONE	CITATION #
CHARGES				FINDER WILL CLAIM PROPERTY	LAB TEST
				YES NO	YES NO

NOTIFICATION FOR RETURN OF PERSONAL PROPERTY

You are responsible for claiming your personal property within 90 days from the above date. The property will be disposed of by the Cottonwood Police Department, if no claim is made prior to that date.

ADVANCE AUTHORIZATION IS REQUIRED IF YOU WISH TO DESIGNATE ANOTHER PERSON TO RECEIVE YOUR PROPERTY.

SIGNATURE

BRIEF SYNOPSIS OF OCCURRENCE: (Also use this space for additional suspects or victims)

31 DAY CALIBRATION CHECK

ITEMIZE AND DESCRIBE PROPERTY

LIST ONLY ONE ITEM PER LINE. NUMBER EACH ITEM ON THE FORM. - Where possible, place each item in plastic bag, and attach property tag to outside of bag.

ITEM	DESCRIPTION	SERIAL #	PROPERTY #
14	CALIBRATION CHECK PAPERWORK	90-004765	100944

Placed in Property Locker #	12	Date	9/5/15	Time	1935
OFFICER:	ofc M. G. L.	SERIAL:	592	PAGE	1 OF 1

DISPOSITION OF PROPERTY:					
<i>Property Items Were:</i>					
1. Returned to Owner		3. Sold at Auction		5. Left at Court	
2. Destroyed		4. T.O.T. City		6. Unable to Locate	
Received By	Date	Time	Remarks		
R. Jones	9/8/15	840			
Property Location	D.W.G.				

INTOXILYZER 8000

Location: COTTONWOOD PD

Serial Number: 80-004765

Core Version: 8105.48

09/05/2015

19:30:46

Standard Lot#: 08915100A2

Last Changed By: R. SCARIM #592

QAS: R. SCARIM #592

COTTONWOOD PD

Operator: R. SCARIM #592

COTTONWOOD PD

Test	g/210L	Time
Air Blank	0.000	19:31:19
0.100 Cal Check	0.096	19:31:39
Air Blank	0.000	19:32:09

Preventative Maintenance
Performed -- Timer Reset

15-009784

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST SCAMM, ROGER G. AGENCY COTTON WOOD PD
DATE 9/5/15 TIME 1921
INTOXILYZER SERIAL # 80-004765 LOCATION COTTONWOOD PD

- (1) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (1) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (1) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (1) 4. Air blank completed.
- (1) 5. Calibration check completed. Test results 0.096 AC.
- (1) 6. Air blank completed.
- (1) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE OR [Signature] 547