



*SMA*  
*372*  
*01/08/15*

INTOXILYZER 8000  
Location: PRESCOTT PD  
Serial Number: 80-006230  
Core Version: 8105.48  
01/08/2015 08:11:01

-----  
Standard Lot#: 1234567890  
Last Changed By: A. A #A  
-----

QAS: S. HILTON #372  
PRESCOTT PD  
-----

Operator: S. HILTON #372  
PRESCOTT PD  
-----

Test	g/210L	Time
Air Blank	0.000	08:11:36
0.100 Cal Check	0.100	08:11:57
Air Blank	0.000	08:12:26

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST SHEAN HULTON AGENCY PRESCOTT P.D.  
DATE 01/08/15 TIME 0813  
INTOXILYZER SERIAL # 80-006230 LOCATION 222 S. MARINA ST.

(~~SA~~) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (~~SA~~) 1. Clock time check.  
(~~SA~~) 2. Date check.

OPERATIONAL TESTS

- (~~SA~~) 1. Alcohol-free subject test result 0. 000 AC.  
(~~SA~~) 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
(~~SA~~) 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
(~~SA~~) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 100 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

All functions proper

SIGNATURE

S H A

SNA 372  
01/08/15

INTOXILYZER 8000  
Location: PRESCOTT PD  
Serial Number: 80-006230  
Core Version: 8105.48  
01/08/2015 08:14:32

---

Standard Lot#: 1234567890  
Last Changed By: A. A #A

---

QAS: S. HILTON #372  
PRESCOTT PD

---

Operator: S. HILTON #372  
PRESCOTT PD

---

Subject: SQAP, TEST  
DOB: 12/19/1973  
Sex: M Weight: 175

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	08:16:23
Diagnostic Test	Pass	08:16:57
Air Blank	0.000	08:17:24
0.100 Cal Check	0.099	08:17:45
Air Blank	0.000	08:18:14
Subject Test	0.000	08:18:35
Air Blank	0.000	08:19:03
Wait	ABT*	
Air Blank	0.000	08:19:37

\*Sequence Aborted

**Not a Successfully Completed Test Sequence**

SNA 372  
01/08/15

INTOXILYZER 8000  
Location: PRESCOTT PD  
Serial Number: 80-006230  
Core Version: 8105.48  
01/08/2015 08:20:52

---

Standard Lot#: 1234567890  
Last Changed By: A. A #A

---

QAS: S. HILTON #372  
PRESCOTT PD

---

Operator: S. HILTON #372  
PRESCOTT PD

---

Subject: SQAP,TEST  
DOB: 12/19/1973  
Sex: M Weight: 175

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	08:21:37
Air Blank	0.000	08:22:06

\*Improper Sample

**Not a Successfully Completed Test Sequence**

SMA 372  
01/08/15

INTOXILYZER 8000  
Location: PRESCOTT PD  
Serial Number: 80-006230  
Core Version: 8105.48  
01/08/2015 08:22:52

---

Standard Lot#: 1234567890  
Last Changed By: A. A #A

---

QAS: S. HILTON #372  
PRESCOTT PD

---

Operator: S. HILTON #372  
PRESCOTT PD

---

Subject: SQAP, TEST  
DOB: 12/19/1973  
Sex: M Weight: 175

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	RFI*	08:23:40
Air Blank	0.000	08:24:08

\*RFI Detect

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000  
Location: PRESCOTT PD  
Serial Number: 80-006230  
Core Version: 8105.48  
01/08/2015

08:25:21

---

Standard Lot#: 1234567890  
Last Changed By: A. A

#A

---

QAS: S. HILTON  
PRESCOTT PD

#372

---

Operator: S. HILTON  
PRESCOTT PD

#372

---

Subject: SQAP,TEST  
DOB: 12/19/1973  
Sex: M

Weight: 175

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	08:26:27
Diagnostic Test	Pass	08:27:01
Air Blank	0.000	08:27:29
0.100 Cal Check	0.101	08:27:49
Air Blank	0.000	08:28:19
Subject Test	0.209*	08:31:26
Air Blank	0.000	08:32:02
Air Blank	0.000	08:32:29
Subject Test	XXX**	08:32:50
Air Blank	0.000	08:33:34

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

**Not a Successfully Completed Test Sequence**

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST SHEAR HILTON AGENCY PRESCOTT P.D.

DATE 01/08/15 TIME 0836

INTOXILYZER SERIAL # 80-006230 LOCATION 222 S. MARINA ST.

- (L) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution          AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (L) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (L) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (L) 4. Air blank completed.
- (L) 5. Calibration check completed. Test results 0. 100 AC.
- (L) 6. Air blank completed.
- (L) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE S. HILTON 372

SMA 372  
01/08/15

INTOXILYZER 8000  
Location: PRESCOTT PD  
Serial Number: 80-006230  
Core Version: 8105.48  
01/08/2015 08:37:34

-----  
Standard Lot#: 1234567890  
Last Changed By: A. A #A  
-----

QAS: S. HILTON #372  
PRESCOTT PD  
-----

Operator: S. HILTON #372  
PRESCOTT PD  
-----

Test	g/210L	Time
Air Blank	0.000	08:38:06
0.100 Cal Check	0.100	08:38:27
Air Blank	0.000	08:38:57

Preventative Maintenance  
Performed -- Timer Reset