

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST S. HILTON AGENCY PRESIDENT P.D.
DATE 11/30/16 TIME 03:04
INTOXILYZER SERIAL # 80-006230 LOCATION PRESIDENT P.D.

- (S) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (S) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(S) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(S) 4. Air blank completed.
(S) 5. Calibration check completed. Test results 0. 100 AC.
(S) 6. Air blank completed.
(S) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE S. Hilton

DPS Form Exh G-2 (Rev 05-01)

INTOXILYZER 8000

Location: PRESCOTT PD

Serial Number: 80-006230

Core Version: 8105.48

11/30/2016

03:04:11

Standard Lot#: 27016100A1

Last Changed By: S. HILTON #372

QAS: S. HILTON #372

PRESCOTT PD

Operator: S. HILTON #372

PRESCOTT PD

Test	g/210L	Time
Air Blank	0.000	03:04:44
0.100 Cal Check	0.100	03:05:05
Air Blank	0.000	03:05:35

Preventative Maintenance
Performed -- Timer Reset



EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST S. Hegam AGENCY PRESCOTT P.P.
DATE 11/30/16 TIME 0306
INTOXILYZER SERIAL # 80-006230 LOCATION PRESCOTT P.P.

(S) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (S) 1. Clock time check.
- (S) 2. Date check.

OPERATIONAL TESTS

- (S) 1. Alcohol-free subject test result 0. 000 AC.
- (S) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- (S) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- (S) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 099 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

FUNCTIONAL PERIOD

SIGNATURE

S. HEGAM

INTOXILYZER 8000

Location: PRESCOTT PD

Serial Number: 80-006230

Core Version: 8105.48

11/30/2016

03:06:52

Standard Lot#: 27016100A1

Last Changed By: S. HILTON

#372

QAS: S. HILTON

#372

PRESCOTT PD

Operator: S. HILTON

#372

PRESCOTT PD

Subject: SQAP, TEST

DOB: 12/19/1973

Sex: M

Weight: 175

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	03:07:48
Diagnostic Test	Pass	03:08:23
Air Blank	0.000	03:08:50
0.100 Cal Check	0.100	03:09:11
Air Blank	0.000	03:09:41
Subject Test	0.000	03:09:57
Air Blank	0.000	03:10:24
Wait	ABT*	
Air Blank	0.000	03:10:58

*Sequence Aborted

SW

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: PRESCOTT PD
Serial Number: 80-006230
Core Version: 8105.48
11/30/2016

03:11:19

Standard Lot#: 27016100A1
Last Changed By: S. HILTON #372

QAS: S. HILTON #372
PRESCOTT PD

Operator: S. HILTON #372
PRESCOTT PD

Subject: SQAP, TEST
DOB: 12/19/1973
Sex: M Weight: 175

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	03:11:58
Air Blank	0.000	03:12:26

*Improper Sample



Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: PRESCOTT PD
Serial Number: 80-006230
Core Version: 8105.48
11/30/2016

03:12:49

Standard Lot#: 27016100A1
Last Changed By: S. HILTON #372

QAS: S. HILTON #372
PRESCOTT PD

Operator: S. HILTON #372
PRESCOTT PD

Subject: SQAP, TEST
DOB: 12/19/1973
Sex: M Weight: 175

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	03:13:27
Air Blank	0.000	03:13:55

*RFI Detect



Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: PRESCOTT PD
Serial Number: 80-006230
Core Version: 8105.48
11/30/2016

03:14:25

Standard Lot#: 27016100A1
Last Changed By: S. HILTON #372

QAS: S. HILTON #372
PRESCOTT PD

Operator: S. HILTON #372
PRESCOTT PD

Subject: SQAP, TEST
DOB: 12/19/1973
Sex: M Weight: 175

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	03:15:34
Diagnostic Test	Pass	03:16:09
Air Blank	0.000	03:16:36
0.100 Cal Check	0.099	03:16:57
Air Blank	0.000	03:17:27
Subject Test	0.242*	03:20:34
Air Blank	0.000	03:21:15
Air Blank	0.000	03:21:42
Subject Test	XXX**	03:22:05
Air Blank	0.000	03:22:39

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST S. Hutton AGENCY Prescott P.P.
DATE 11/30/16 TIME _____
INTOXILYZER SERIAL # 80-006230 LOCATION Prescott P.P.

- (S) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (S) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(S) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(S) 4. Air blank completed.
(S) 5. Calibration check completed. Test results 0. 099 AC.
(S) 6. Air blank completed.
(S) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE _____
S. Hutton

DPS Form Exh G-2 (Rev 05-01)

INTOXILYZER 8000

Location: PRESCOTT PD

Serial Number: 80-006230

Core Version: 8105.48

11/30/2016

03:23:13

Standard Lot#: 27016100A1

Last Changed By: S. HILTON #372

QAS: S. HILTON #372

PRESCOTT PD

Operator: S. HILTON #372

PRESCOTT PD

Test	g/210L	Time
Air Blank	0.000	03:23:44
0.100 Cal Check	0.099	03:24:05
Air Blank	0.000	03:24:35

Preventative Maintenance
Performed -- Timer Reset

